



- 119/50 Top nut
- 119/78 Frame, complete
- 119/39 Inner Cowl
- 119/41 Air Chamber
- 119/36 Outer Hood
- 119/42 Lower Part of Hood
- 119/32 Holder for Flame Spreader
- 119/31 Flame Spreader
- 119/33 Incandescent Mantle
- 119/24 Glass Chimney
- 119/23 Nut for Lantern Frame
- 119/19 Burner Sheath
- 119/49 Aluminium Packing
- 12/47 Finer Cap with Safety Valve
- 12/57 Valve Spring
- 12/56 Valve Diaphragm
- 12/55 Valve Packing
- 11/48 Lid Packing
- 0/43 Air Screw
- 1/64 Leather Packing
- 0/68 Pump Valve

- 119/44 Topscrew
- 119/21 Top Cowl
- 119/48 Gas Mixer
- 119/28 Nipple
- 119/87 Cleaning Needle
- 119/67 Catch for Hood
- 119/09 Coupling Box
- 119/10 Needle Rod
- 119/34 Vaporizer
- 119/06 Spirit Cup
- 119/05 Aluminium Packing
- "A"
- 119/48 Valve Packing
- 119/12 Spindle Box
- 119/14 Packing Screw
- 108/96 Hand-Wheel
- 119/72 Supporting Ring
- 119/53 Lid for Manometer Seat
- 0/59 Lead Pack.
- 0/60 Pump Knob
- 1/61 Pump Cap
- 1/75 Pump Rod